


# Next Day Blinds

## Installation Instructions | Honeycomb & Pleated Shades Lift Systems: for Cord Lock lift systems

### A Getting Started

The Parts: Before starting, please remove and identify the following parts required for the installation of your shades:



Installation Brackets



Installation Screws




Extension Brackets  
(optional)



Swivel Brackets (optional)



Spacer Blocks (optional)



Hold Down Brackets  
for Doors (optional)

### B The Tools

To install your Next Day Blinds Honeycomb or Pleated Shade, you will need a few basic tools:


- Measuring tape
- Power drill with 1/4" hex head attachment and/or Phillips Head Screwdriver
- Pencil

**Important Note:** Screws provided are for installation into wooden frames only. For metal surfaces, use suitable sheet metal screws and pre-drill holes. For concrete, stone, brick, or tile, use a carbide drill and appropriate anchors and screws. For wallboard or plaster, use hollow wall anchors and/or longer screws to reach framing or stud. In all cases, follow the fastener manufacturer's recommendations.

### C Sorting Your Blinds

On top of the headrail of your Next Day Blinds Honeycomb or Pleated Shade, there is a sorting label. On this label, you will recognize:

1. Order size of the blind
2. Room location (If not present, info not given at time of order)
3. Whether the blind was ordered for inside mount (IB), or outside mount (OB)




### D Bracket Spacing

Two installation brackets are positioned on the mounting surface so that their centerlines will be 2 1/4" in from the ends of the shade. If more than two brackets are required follow instructions shown below.

**Measure and mark all bracket centerlines.** Note: For optional swivel brackets, position the holes (for mounting screws) 3" in from the ends of the shade.



Shade Width	Number of Brackets
To 31"	2
31" To 79"	3
79" To 127"	4
127" To 174"	5



### E Bracket Installation


#### Inside Mount Standard

1. With inside mount applications, one installation screw is used through the top of each installation bracket into the underside of the top of the window frame (Fig. 1).
2. If more than two brackets are required, additional brackets are spaced evenly between the two end brackets. Please refer back to Section D for details.
3. To attach the brackets, the flat surface of the top frame must be at least 1" deep. If less than 1" deep swivel brackets are required (Fig. 2).




### Inside Mount Swivel (optional)

Swivel brackets can be used on inside mount (IB) only. One screw is used to attach each swivel bracket. Swivel brackets require less mounting depth than standard installation brackets. (Bracket attachment requires a solid mounting surface only 1/2" deep. Shades will mount securely but will not fully recess.)




Honeycomb shades 3/8" pleat size.  
Pleated shades 1" pleat size.




Honeycomb shades only.  
3/4" pleat size & double cell.

### Outside Mount Standard

1. With outside mount applications, two installation screws are used to attach the back of each installation bracket to the flat vertical surface. In most instances this will be a flat area on the window trim.
2. Before tightening the screws, check to be sure the tops of all the installation brackets are perfectly horizontal and aligned at the same height. Please refer back to Section D for details. (To attach the brackets, the flat vertical surface must be at least 1/2" high.)



Honeycomb shades 3/8" pleat size.  
Pleated shades 1" pleat size.




Honeycomb shades only.  
3/4" pleat size & double cell.

### F Installing Spacer Blocks (optional)

Spacer blocks are used to project the installation brackets away from the mounting surface when additional shade clearance is needed. Spacer blocks are usually used when the shade is mounted above the trim. Each spacer block increases clearance by 3/8"; use a maximum of two per installation bracket.

1. Check that your installation screws are long enough to securely attach the installation bracket and the spacer blocks.
2. Make sure the tops of the installation brackets are perfectly horizontal and aligned at the same height before tightening the screws. Please refer back to Section D for details.




Honeycomb shades all sizes.  
Pleated shades 1" pleat size.

### G Installing Extension Brackets (optional)

Extension brackets can project the installation brackets up to 2 1/2" from the mounting surface.

1. Connect the extension bracket with the installation bracket using the machine screw and speed nut, which are parts included with each extension bracket. Be sure to use the same hole on all the extension brackets, so that each installation bracket projects the same distance from the mounting surface.
2. Make sure the tops of the extension brackets are perfectly horizontal and aligned at the same height and use two screws to attach to wall. Please refer back to Section D for details.



Honeycomb Shades all sizes.  
Pleated Shades 1" pleat size.

## H Installing Your Shades Into the Brackets

### Standard Brackets

1. Make sure tab screw is loose, and tab is hanging freely (Fig. 1).
2. Tilt and slip the inside lip of the headrail over the installation brackets' front ledges as shown (Fig. 2).
3. Raise back of headrail so that it fits completely inside the notches in the back of brackets (Fig. 3).
4. To secure headrail to brackets tighten tab screws (Fig. 4).




Figure 1




Figure 2




Figure 3




Figure 4

### Swivel Brackets (optional)

1. To open brackets turn brackets' arms as shown (Fig. 2).
2. To secure the swivel bracket to the headrail turn the swivel bracket's arm counter clockwise as shown (Fig. 3).
3. Slip brackets' tabs to fit under headrail's inside lip. Push arm tight against front of headrail (Fig. 4).




Figure 1




Figure 2




Figure 3




Figure 4


## I Operating Honeycomb or Pleated Shades

1. Keep the cord close to the plane of the fabric when operating the shade; for best results, do not pull the cord away from the shade more than 15°.
2. To disengage the locking mechanism, move the cord toward the center of the shade approximately 30° from the vertical position. Raise or lower the shade while holding the cord at this angle.
3. To engage the locking mechanism, return the cord to the vertical position.

## J Installing Hold Down Bracket (optional)

If mounting to a door, your shade should include hold down brackets.

1. With the shade at its full drop, place the pins on the hold down brackets into the holes in the bottom rail end caps and mark where to drill the mounting holes.
2. Attach the hold down brackets with one screw through the side hole or two screws through the end holes. Be sure both bracket pins are aligned and level.



### Child Safety

Next Day Blinds is committed to incorporating the latest and most effective child-safe technologies in our products. All corded Next Day Blinds Honeycomb & Pleated Shades feature breakaway cord devices that separate under pressure. For more details about Next Day Blinds' commitment to child safety visit [nextdayblinds.com/childsafety](http://nextdayblinds.com/childsafety).

### Cleaning and Care

In order to keep your window treatments looking new, follow the recommended methods for care and maintenance. Regular care will result in better appearance and performance from your window coverings.

HONEYCOMB: Light Filtering = X / Light Blocking = Z / PLEATED: X

Dusting	Hand-Held Vacuum	Compressed Air	Hair Dryer	Spot Cleaning	Water Immersion	Ultrasonic Cleaning
XZ	XZ			XZ	X	